



RIPSTAAL DRYWALL REVEAL®



INSTRUCTIONS FOR USE

 **Ripstaal**
CONSTRUCTION PRODUCTS



RIPSTAAL DRYWALL REVEAL[®]

THE COMPLETE SOLUTION
FOR QUICKLY AND NEATLY
FINISHING REVEALS

6 simple steps

Measure the length of the reveal and cut the drywall reveal and the connection profile to size.

1

Affix the connection profile to the frame and place the drywall reveal inside the profile.

2

Cover the back of the drywall reveal with a non-expanding construction or adhesive foam. Use a try square and a spirit level to ensure that the drywall reveal is perpendicular to the frame.

3

When the construction/adhesive foam has set, seal the seams between the drywall reveals themselves, and the seams between the drywall reveals and the window sill.

4

The walls to the sides of the reveal can now be plastered over.
This is not necessary for the reveal itself.

5

The drywall reveal can be finished using most any decorative material.
Read the requirements for use of the products in question for possible primers.

6

 **Ripstaal**
CONSTRUCTION PRODUCTS